#### 2.3 Constitutive Relations

- 2.3.1 Definitions
  - Homogeneity, Isotropy, Elasticity, Linearity
  - Nonlinear Material Response
- 2.3.2 Generalized Hooke's Law
- 2.3.3 Strain Energy and Complementary Strain Energy Density Functions
- 2.3.4 Decomposition of Strain Energy Density Into Volumetric and Distortional Components
- 2.3.5 Thermal Strains and Thermal Stresses

# **Constitutive Relations**

The analysis of stress and strains - equations of motion; and strain-displacement relationships apply to any, regardless of the material properties.

Since the response depends on the material, supplemental relations (constitutive relations) representing the type of material are needed.

Constitutive relations are semi-empirical: based on experimental observation.

Relations between stress components

$$\sigma_{xx}$$
 ,  $\sigma_{yy}$  ,  $\sigma_{zz}$  ,  $\tau_{yz}$  ,  $\tau_{zx}$  ,  $\tau_{xy}$ 


and strain components

$$\varepsilon_{\mathsf{x}}$$
 ,  $\varepsilon_{\mathsf{y}}$  ,  $\varepsilon_{\mathsf{z}}$  ,  $\gamma_{\mathsf{yz}}$  ,  $\gamma_{\mathsf{zx}}$  ,  $\gamma_{\mathsf{xy}}$ 

# **Definitions**

#### Homogeneity

A material property is called homogeneous if it does not change from point to point in the body (i.e., it is invariant under coordinate translation).



#### Isotropy

A material property is called isotropic if it does not change with direction (i.e., it is invariant under coordinate rotation).



# **Definitions**


#### Isotropy

A material property is called isotropic if it does not change with direction (i.e., it is invariant under coordinate rotation).



#### Elasticity


The material is called elastic if its loading and unloading curves coincide.



# **Definitions**


#### **Elasticity**

The material is called elastic if its loading and unloading curves coincide.



#### Linearity


Refers to linear dependence of stresses on strains.




## **Definitions**


### **Nonlinear Material Response**


- Nonlinear elastic response
  - single-valued relationship between stresses and strains



- Inelastic response
  - · time independent
  - time dependent









# Definitions

- Inelastic response
  - · time independent
  - · time dependent







Generally, more than one material model is needed for the entire stress-strain-temperature range of interest.














# Generalized Hooke's Law

Hooke's Law for One Dimensional Stress / Strain State

$$\sigma = E \varepsilon$$


where  $\sigma$ ,  $\epsilon$  = uniaxial mechanical stress and strain

E = Young's modulus




#### **Generalized Hooke's Law**


- For linearly elastic isotropic material
  - Linear (extensional) strain in the x direction, ε<sub>x</sub>




associated with









Linear strains

$$\sigma_{xx} : \frac{1}{E} \sigma_{xx}$$

$$\sigma_{yy} : -\frac{v}{E} \sigma_{yy}$$


$$\sigma_{zz} : -\frac{v}{E} \sigma_{zz}$$


$$\varepsilon_{x} = \frac{1}{E} \left( \sigma_{xx} - \nu \, \sigma_{yy} - \nu \, \sigma_{zz} \right)$$

Shearing strain in plane xy

$$\gamma_{xy} = \frac{1}{G} \tau_{xy}$$


# **Generalized Hooke's Law**





#### Comments on Generalized Hooke's Law

- For linearly elastic isotropic materials
  - Extensional strains are associated with normal stresses
  - Shearing strain in each of the coordinate planes is associated with the shearing stress on the same plane



#### Comments on Generalized Hooke's Law

Two independent material coefficients


E = Young's modulus


υ = Poisson's ratio


G = shear modulus

= E / 2(1+v)

- Anisotropic mechanical properties
  - extensional and shear effects are coupled








#### Comments on Generalized Hooke's Law

- Anisotropic mechanical properties
  - extensional and shear effects are coupled
- For nonhomogeneous materials, E and V are functions of the coordinates.



 The relations shown apply for the case of strains and stresses caused by mechanical loading (not for thermal, magnetic and/or electric fields).

Adding the first three equations:

$$(\varepsilon_{x} + \varepsilon_{y} + \varepsilon_{z}) = \frac{1-2\upsilon}{E} (\sigma_{xx} + \sigma_{yy} + \sigma_{zz})$$

$$= \frac{1}{3K} (\sigma_{xx} + \sigma_{yy} + \sigma_{zz})$$
where  $K = \frac{E}{3(1-2\upsilon)} = \text{bulk modulus}$ 
or  $(\frac{1}{3} J_{1}) = \frac{1}{3K} (\frac{1}{3} I_{1})$ 

## Generalized Hooke's Law

$$(\epsilon_x + \epsilon_y + \epsilon_z) = \frac{1-2\upsilon}{E} (\sigma_{xx} + \sigma_{yy} + \sigma_{zz})$$

$$= \frac{1}{3K} (\sigma_{xx} + \sigma_{yy} + \sigma_{zz})$$
where  $K = \frac{E}{3(1-2\upsilon)} = \text{bulk modulus}$ 
or  $\left(\frac{1}{3}J_1\right) = \frac{1}{3K}\left(\frac{1}{3}I_1\right)$ 

which is a relation between the volumetric strain and volumetric stress components.

## Strain Energy and Complementary Strain Energy Density Functions


For elastic materials and uniaxial stress state

$$\sigma \varepsilon = U + C =$$

U = strain energy density (strain energy per unit volume)

$$=\int \sigma d\varepsilon$$

C = complementary strain energy density (complementary strain energy per unit volume)




## Strain Energy and Complementary Strain Energy Density Functions

U = strain energy density (strain energy per unit volume)

C = complementary strain energy density (complementary strain energy per unit volume)

$$=\int \epsilon d\sigma$$



## Strain Energy and Complementary Strain Energy Density Functions

From which


$$\sigma = \frac{dU}{d\varepsilon}$$
$$\varepsilon = \frac{dC}{d\sigma}$$

For linearly elastic materials

$$U = \frac{1}{2} E \varepsilon^2$$

$$C = \frac{1}{2E} \sigma^2$$

 For the case of pure shear linearly elastic materials



## Strain Energy and Complementary Strain Energy Density Functions

· For linearly elastic materials


$$U = \frac{1}{2} E \epsilon^2$$

$$C = \frac{1}{2E} \sigma^2$$

 For the case of pure shear linearly elastic materials


$$U = \frac{1}{2} G \gamma^2$$


$$C = \frac{1}{2G} \tau^2$$







 For the three-dimensional stress state, the strain energy density, and the complementary strain energy density are given by:





## Strain Energy and Complementary Strain Energy Density Functions






 Total strain energy and total complementary strain energy are given by:

$$\overline{U} = \int_{V} U \, dV$$

$$\overline{C} = \int_{V} C \, dV$$




# Decomposition of Strain Energy Density into Volumetric and Distortional Components

 The principal stresses and strains can be decomposed as follows:

$$\begin{cases}
\sigma' \\
\sigma''' \\
\sigma''''
\end{cases} = \frac{1}{3} \left\{ \begin{matrix} I_1 \\ I_1 \\ I_1 \end{matrix} \right\} + \left\{ \begin{matrix} \sigma'' - \frac{1}{3} I_1 \\ \sigma''' - \frac{1}{3} I_1 \\ \sigma''' - \frac{1}{3} I_1 \end{matrix} \right\}$$
volumetric deviatoric

where 
$$I_1 = \sigma^1 + \sigma^{11} + \sigma^{111}$$




# Decomposition of Strain Energy Density into Volumetric and Distortional Components

### Analogously,

$$\begin{cases}
\epsilon^{1} \\
\epsilon^{\parallel} \\
\epsilon^{\parallel}
\end{cases} = \frac{1}{3} \begin{Bmatrix} J_{1} \\
J_{1} \\
J_{1} \end{Bmatrix} + \begin{Bmatrix}
\epsilon^{1} - \frac{1}{3} J_{1} \\
\epsilon^{\parallel} - \frac{1}{3} J_{1} \\
\epsilon^{\parallel} - \frac{1}{3} J_{1}
\end{Bmatrix}$$

where  $J_1 = \varepsilon^I + \varepsilon^{II} + \varepsilon^{III}$ 

volumetric deviatoric



# Decomposition of Strain Energy Density into Volumetric and Distortional Components

#### For linearly elastic materials


$$U = \frac{1}{2} \left( \sigma^{\dagger} \epsilon^{\dagger} + \sigma^{\parallel} \epsilon^{\parallel} + \sigma^{\parallel} \epsilon^{\parallel} \right)$$
$$= U_{\text{vol.}} + U_{\text{dist.}}$$


where 
$$U_{\text{vol.}} = \frac{1}{6} I_1 J_1$$

#### but, for isotropic materials

$$\begin{cases} \epsilon^{\text{I}} \\ \epsilon^{\text{III}} \\ \epsilon^{\text{III}} \end{cases} = \frac{1}{E} \begin{bmatrix} 1 & -\upsilon & -\upsilon \\ -\upsilon & 1 & -\upsilon \\ -\upsilon & -\upsilon & 1 \end{bmatrix} \begin{cases} \sigma^{\text{I}} \\ \sigma^{\text{II}} \\ \sigma^{\text{III}} \end{cases}$$

$$J_1 = \frac{1}{3K} I_1$$







# Decomposition of Strain Energy Density into Volumetric and Distortional Components

#### Therefore,

$$U = \frac{1}{2E} \left[ (\sigma^{I})^{2} + (\sigma^{II})^{2} + (\sigma^{III})^{2} - 2\upsilon (\sigma^{I}\sigma^{II} + \sigma^{II}\sigma^{III} + \sigma^{III}\sigma^{I}) \right]$$

$$U_{\text{vol.}} = \frac{1}{18K} (I_1)^2 +$$






# Decomposition of Strain Energy Density into Volumetric and Distortional Components


### Therefore,

$$U_{\text{dist.}} = U - U_{\text{vol.}}$$

$$= \frac{1}{12G} \left[ (\sigma^{\text{I}} - \sigma^{\text{II}})^2 + (\sigma^{\text{II}} - \sigma^{\text{III}})^2 + (\sigma^{\text{III}} - \sigma^{\text{I}})^2 \right]^{\frac{1}{2}}$$

where 
$$G = \frac{E}{2(1 + \frac{E}{2})}$$





## Thermal Strains and Thermal Stresses

Hooke's Law for One Dimensional Stress / Strain State

$$\sigma = E(\varepsilon - \alpha T)$$

where

ε is the total strain

 $\alpha T$  is the thermal strain

σ is related to the mechanical strain

